

THE ENVIRONMENTAL COMPLIANCE EXPERTS



DESCRIPTION	QTY
POLY PADS HAZCHEM - 48CM X 43CM X HEAVY WEIGHT - DIMPLED & PERFORATED	40
HAZSORB 30L VBAG	3
POLYPROPYLENE ABSORBENT SOCKS - HAZCHEM - 75MM X 1.2M	4
POLYPROPYLENE ABSORBENT SOCKS - HAZCHEM - 75MM X 3M	1
POLY HAZCHEM PILLOWS - 45CM X 45CM	1
PAIR OF NITRILE GLOVES	2
CONTAMINATED WASTE BAGS - 450MM X 720MM	10
DUST PAN AND BRUSH	1
SPILL KIT STICKER AND INSTRUCTIONS	1

SPILL ABSORPTION PROCEDURE

- 1 Assess the Spill:** Identify the liquid and review its SDS to ensure proper safety precautions and use of appropriate PPE.
- 2 Contain the Spill:** Create a barrier using Hazchem Containment Booms or Containment Socks.
- 3 Control Leaks:** Place Hazchem Pillows under any ongoing leaks.
- 4 Apply Absorbent:** Cover the spill with HazSorb loose absorbent.
- 5 Sweep the Area:** Use a stiff broom to spread absorbent over the spill.
- 6 Reapply if Needed:** If the area remains wet or oily, apply more HazSorb until dry.
- 7 Wipe Residue:** Use Hazchem pads to clean any remaining liquid or affected equipment.
- 8 Dispose Properly:** Place all saturated materials in waste disposal bags and dispose of them per local regulations.
- 9 Report Incident:** Complete and file an incident report.
- 10 Restock Kit:** Conduct an inventory and replace all used items.

To re-order call 0434 314 803