

THE ENVIRONMENTAL COMPLIANCE EXPERTS



DESCRIPTION	QTY
POLY PADS OIL ONLY - 48CM X 43CM X HEAVY WEIGHT - DIMPLED & PERFORATED	20
POLYPROPYLENE ABSORBENT SOCKS - OIL ONLY - 75MM X 1.2M	1
PAIR OF NITRILE GLOVES	1
CONTAMINATED WASTE BAGS - 450MM X 720MM	3
SPILL KIT STICKER AND INSTRUCTIONS	1

SPILL ABSORPTION PROCEDURE

- 1 Assess the Spill:** Identify the liquid and review its SDS to ensure proper safety measures and suitable PPE are used.
- 2 Contain the Spill:** Create a barrier using Hydrocarbon Containment Booms or Containment Socks.
- 3 Control Leaks:** Place Hydrocarbon Pillows under ongoing leaks.
- 4 Apply Absorbent Pads:** Cover the spill with Absorbent White Hydrocarbon Pads.
- 5 Drag and Contain:** Use Booms or Socks to drag the spill across the water, minimizing the affected area.
- 6 Remove and Reapply:** Remove soaked pads; apply more if needed. Wipe clean any remaining areas or equipment.
- 7 Dispose Properly:** Place all saturated materials in the waste disposal bag and dispose of them per local regulations.
- 8 Report Incident:** Complete and file an incident report.
- 9 Restock Kit:** Conduct an inventory and replace all used items.

To re-order call 0434 314 803