

THE ENVIRONMENTAL COMPLIANCE EXPERTS



DESCRIPTION	QTY
POLY PADS OIL ONLY - 48CM X 43CM X HEAVY WEIGHT - DIMPLED & PERFORATED	20
POLYPROPYLENE ABSORBENT SOCKS - OIL ONLY - 75MM X 1.2M	1
PAIR OF NITRILE GLOVES	1
CONTAMINATED WASTE BAGS - 450MM X 720MM	3
SPILL KIT STICKER AND INSTRUCTIONS	1

SPILL ABSORPTION PROCEDURE

- 1 **Assess the Spill:** Identify the liquid and review its SDS to ensure proper safety precautions and use of appropriate PPE.
- 2 **Contain the Spill:** Use absorbent material or containment socks to prevent spreading.
- 3 **Apply Absorbent:** Cover the spill completely.
- 4 **Check for Dryness:** If the absorbent mix isn't dry, apply more until it appears dry.
- 5 **Sweep the Area:** Use a stiff broom to spread absorbent over the spill zone.
- 6 **Reapply if Needed:** Add more absorbent if wet spots or oily residue remain.
- 7 **Wipe Residue:** Use pads to clean any remaining affected surfaces.
- 8 **Dispose Properly:** Dispose of all waste in accordance with local regulations.
- 9 **Report Incident:** Complete and file an incident report.
- 10 **Restock Kit:** Replenish the spill kit with replacement items.

To re-order call 0434 314 803